

頁	商社	Vol.31品番	品名	Vol.31上代(紙版)	上代変更	廃番	頁	順	サイズ	重量g	強化	直火OK	軽量	耐熱	IH	原産国	有田焼	永久番号	旧永久番号(旧雅陶会)	備考	品番(旧陶里)	品番(旧雅陶会)
638	29	63801-291	黒一珍飯器(小)蓋付	3,700			638	1	10.5×8.5cm	340	強化							312963801	0222462011			448-07-225
638	29	63802-291	黒一珍飯器(小)(身)	3,000			638	2	10.5×7.6cm	300	強化							312963802	0222462012			448-08-225
638	29	63803-291	花洒飯器(身)	3,300	3,500		638	3	10.7×7.2cm	258	強化							312963803	0322444001			448-03-225
638	29	63804-291	茶杉木蓋	1,900	2,000		638	4	12×12cm	29								312963804	0322444002			448-04-225
638	29	63805-291	紫吹き飯器(小)蓋付	3,500	3,700		638	5	12.5×8.5cm	335								312963805	0222462019			448-13-225
638	29	63806-291	紫吹き飯器(小)(身)	2,700	2,950		638	6	10.1×7.5cm	295								312963806	0222462020			448-14-225
638	18	63807-181	アメ釉銀彩飯器身	3,150	3,350		638	7	10.5×8cm	265								281842005			50603-180	
638	18	63808-181	アメ釉銀彩木蓋	1,100	1,150		638	8	11cm	37								281842006			50604-180	
638	22	63809-221	赤楽十草飯器(蓋付)	2,870		廃番	638	9	11×8cm	395								252238106			50612-220	
638	30	63810-301	志野飯器(蓋付)	3,000			638	10	11×7.9cm	483								253038110			50619-300	
638	30	63811-301	志野飯器(身)	2,350			638	11	11×8cm	440								273040435			50620-300	
638	32	63812-321	鉄線花筒型飯器(小)(身)	1,980			638	12	10.5×7cm									303250601			50601-320	
638	32	63813-321	鉄線花筒型飯器 木蓋	850	1,180		638	13	11.5×11.5×2cm									303250602			50602-320	
638	64	63814-641	金筋ゆず黒蓋付飯器(組)	2,600		廃番	638	14	12.5×11.5×9cm	394								316463814	0164478011			448-09-645
638	64	63815-641	金筋ゆず黒飯器(身)	2,150		廃番	638	15	10.6×7.5cm	357								316463815	0164478012			448-10-645
638	51	63816-511	一珍ピンク渦蓋付飯器	2,400	3,150		638	16	12.3×11.4×9.6cm	407								315163816	0151478015			448-11-515
638	51	63817-511	一珍ピンク渦飯器(身)	1,850	2,500		638	17	10.7×8.1cm	362								315163817	0151478016			448-12-515
638	33	63818-331	手描笹花飯器(蓋付)	2,400	2,700		638	18	12.7×6.5cm	316								253338027			50637-330	
638	12	63819-121	火色志野飯器	2,300			638	19	10.8×7.8cm	330								291244433			50642-120	
638	12	63820-121	火色志野飯器木蓋	440			638	20	12.5×11.5×2cm	40								291244434			50643-120	
638	12	63821-121	灰釉ビードロ飯器	2,250			638	21	10.8×7.8cm	330								291244431			50640-120	
638	12	63822-121	灰釉ビードロ飯器木蓋	440			638	22	12.5×11.5×2cm	40								291244432			50641-120	
638	05	63823-051	錦天目飯器(蓋付)	2,400			638	23	11×8cm	423								280542120			50707-050	
638	49	63824-491	ヒスイ蓋付飯器	2,200	2,400		638	24	11.8×9.3cm	420								314963824	0149478029			448-19-495
638	49	63825-491	ヒスイ飯器(身)	1,680	1,880		638	25	10.5×8cm	380								314963825	0149478030			448-20-495
638	05	63826-051	鉄砂飯器(プラスチック蓋付)	2,200	2,350		638	26	11×8cm									300550704			50704-050	
638	05	63827-051	黄瀬戸飯器(プラスチック蓋付)	2,200	2,350		638	27	11×8cm									300550703			50703-050	
638	49	63828-491	茶益子丸紋蓋付飯器	2,200	2,400		638	28	11.8×9.3cm	420								314963828	0149478025			448-15-495
638	49	63829-491	茶益子丸紋飯器(身)	1,680	1,880		638	29	10.5×8cm	380								314963829	0149478026			448-16-495
638	49	63830-491	益子ススキ蓋付飯器	2,200	2,400		638	30	11.8×9.3cm	420								314963830	0149478027			448-17-495
638	49	63831-491	益子ススキ飯器(身)	1,680	1,880		638	31	10.5×8cm	380								314963831	0149478028			448-18-495
638	18	63832-181	花かご飯器(身)	2,150	2,800		638	32	11×7.8cm	266								251838136			50630-180	
638	18	63833-181	プラスチック蓋	450			638	33	12cm	43								251838137			50631-180	
638	07-49	63834-07-491	ゆず天目飯器(蓋付)	2,050	2,400		638	34	10.5×7.7cm	445								250738113	0149478023			50708-070
638	33	63835-331	銀彩刷毛筒型飯器(蓋付)	2,000	2,200		638	35	11.5×9.8cm	440								263338525			50716-330	
638	33	63836-331	銀彩刷毛筒型飯器身のみ	1,500	1,650		638	36	10.7×7.7cm	400								263338524			50717-330	
638	33	63837-331	黒唐津オリベ流筒型飯器(蓋付)	2,000	2,200		638	37	11.5×9.8cm	440								263338521			50714-330	
638	33	63838-331	黒唐津オリベ流筒型飯器身のみ	1,500	1,650		638	38	10.7×7.7cm	400								263338520			50715-330	
638	33	63839-331	錦天目筒型飯器(蓋付)	2,000	2,200		638	39	11.5×9.8cm	440								263338517			50712-330	
638	33	63840-331	錦天目筒型飯器身のみ	1,500	1,650		638	40	10.7×7.7cm	400								263338516			50713-330	
638	25	63841-251	うぐいす流し飯器(蓋付)	2,200			638	41	10.5×7.5cm	431								252538016			50709-250	
638	33	63842-331	錦花飯器身のみ	1,900	2,100		638	42	12.7×6.5cm	273								253338025			50638-330	
638	33	63843-331	プラスチック蓋	500	550		638	43	13.5cm	34								253338026			50639-330	
639	05	63901-051	十草飯器(蓋付)	1,980			639	1	10.5×8cm	472								250538119			50711-050	
639	05	63902-051	間取桔梗飯器(蓋付)	1,980			639	2	10.5×8cm	463								250538020			50710-050	
639	51	63903-511	柿釉蓋付飯器	1,930	2,400		639	3	11.3×8.6cm	290								315163903	0151479019			449-11-515
639	51	63904-511	柿釉飯器(身)	1,220	1,500		639	4	11.3×7.5cm	227								315163904	0151479020			449-12-515
639	51	63905-511	ヒワ釉蓋付飯器	1,930	2,400		639	5	11.3×8.5cm	290								315163905	0151479017			449-13-515
639	51	63906-511	ヒワ釉飯器(身)	1,220	1,500		639	6	11.3×7.5cm	227								315163906	0151479018			449-14-515
639	18	63907-181	華備前(土物)玉淵飯器(身)	1,900	2,100		639	7	11×8cm	352								251855712			50632-180	
639	18	63908-181	華備前(土物)木蓋	650			639	8	11cm	47								251855713			50633-180	
639	12	63909-121	粉引錦若芽飯器(身)	1,500			639	9	11.5×7.8cm									311263909				
639	12	63910-121	粉引錦若芽飯器(フタ)	360			639	10	12×1.5cm									311263910				
639	18	63911-181	淡雪 三色吹飯器(身のみ)	1,800	2,000		639	11	11×8cm	290								291844416			50701-180	
639	18	63912-181	プラスチック蓋	450			639	12	12cm	44								291844417			50702-180	
639	51	63913-511	窯変ピンク蓋付飯器	1,760	2,200		639	13	12.5×10cm	418								315163913	0151478041			449-05-515
639	51	63914-511	窯変ピンク飯器	1,220	1,550		639	14	10.6×7.8cm	373								315163914	0151478042			449-06-515
639	51	63915-511	粉引グリーン吹蓋付飯器	1,760	2,200		639	15	12.3×11.4×9cm	418								315163915	0151478033			449-01-515
639	51	63916-511	粉引グリーン吹飯器(身)	1,220	1,550		639	16	11×7.6cm	373								315163916	0151478034			449-02-515
639	51	63917-511	備前白吹き蓋付飯器	1,760	2,200		639	17	12.3×11.4×9cm	418								315163917	0151478031			448-21-515
639	51	63918-511	備前白吹き飯器(身)	1,220	1,550		639	18	11×7.6cm	373								315163918	0151478032			448-22-515
639	08	63919-081	kasaneそば釉飯器	1,650	1,880		639	19	12×8.3cm									300850615			50615-080	
639	08	63920-081	kasaneそば釉受け皿 小	1,200			639	20	12.3×1.8cm									300850616			50616-080	
639	08	63921-081	kasaneトルコ釉飯器	1,650	1,880		639	21	12×8.3cm									300850613			50613-080	
639	08	63922-081	kasaneトルコ釉受け皿 小	1,200			639	22	12.3×1.8cm									300850614			50614-080	

639	18	63923-181	赤絵小花飯器身	1,350	1,380		639	23	12.6×7.2cm	301							251838035			50705-180	
639	18	63924-181	木蓋	1,050			639	24	14.5×13.5cm	53							251838036			50706-180	
639	12	63925-121	グリーン文字粉引ライス丼	1,200			639	25	11.5×7.8cm	250							251238033			50727-120	
639	12	63926-121	飯器の蓋	360			639	26	12×1.5cm	40							251238141			50728-120	
639	33	63927-331	伊賀織部飯器(木蓋付)	1,200	1,400		639	27	10.8×7.5cm	320							253338037			50729-330	
639	40	63928-401	白釉口罎飯器	1,200	1,480		639	28	10.5×8.1cm	284							314063928				
639	40	63929-401	焼杉木蓋	650	780		639	29	12×11.5×1.8cm	32							314063929				
639	40	63930-401	窯変玉虫飯器	1,200	1,480		639	30	10.5×8.1cm	284							314063930				
639	40	63931-401	焼杉木蓋	650	780		639	31	12×11.5×1.8cm	32							314063931				
639	22	63932-221	天目多用鉢(P蓋付)	1,020	1,130		639	32	13×7cm	420							262238536			50730-220	
639	46	63933-461	手造御本手口反飯器	3,000	3,500		639	33	12.5×8.5cm	300							314663933	0502449015			449-15-025
639	45	63934-451	志野赤絵飯器(蓋付)	3,550		麝香	639	34	11×8cm	480							254538103			50607-450	
639	45	63935-451	志野赤絵飯器(身)	2,900		麝香	639	35	11×8cm	380							314563935	0108478004			448-02-085
639	46	63936-461	石焼こす巻飯器	2,600		麝香	639	36	11×7.5cm	400							314663936	0102479033			449-18-025
639	29	63937-291	白磁筒型飯器(小)	2,500			639	37	10.3×7.4cm	295	強化						312963937	0222463030			449-20-225
639	45	63938-451	粉引鉄彩飯器(蓋付)	3,250	3,800		639	38	9.5×7.5cm	360							254538105			50611-450	
639	45	63939-451	粉引鉄彩飯器(身)	2,400	2,850		639	39	9.5×7.5cm	310							314563939	0108478006			448-06-085
639	46	63940-461	石焼かいらぎ飯器	1,820		麝香	639	40	10.5×6cm	400							314663940	0102479034			449-19-025
639	49	63941-491	柚子天目飯器(身)	1,680	1,880		639	41	10.5×8cm	380							314963941	0149478024			448-24-495