

頁	商社	Vol.31品番	品名	Vol.31上代(紙版)	上代変更	廃番	頁	順	サイズ	重量g	強化	直火OK	軽量	耐熱	IH	原産国	有田焼	永久番号	旧永久番号(旧雅陶会)	備考	品番(旧陶里品番)	品番(旧雅陶会)
656	43	65601-431	灰ビードロ飯碗(小)	3,500			656	1	11.3×5.8cm									314365601				
656	43	65602-431	灰ビードロ飯碗(大)	3,750			656	2	12×6.8cm									314365602				
656	43	65603-431	黒銀彩立線飯碗(小)	3,500			656	3	11.3×5.8cm									314365603				
656	43	65604-431	黒銀彩立線飯碗(大)	3,750			656	4	12×6.8cm									314365604				
656	43	65605-431	黒銀彩ハケ目立線飯碗(小)	3,500			656	5	11.3×5.8cm									314365605				
656	43	65606-431	黒銀彩ハケ目立線飯碗(大)	3,750			656	6	12×6.8cm									314365606				
656	46	65607-461	織部丸紋中平	1,510	1,670		656	7	12×5cm	170								314665607	0102480003			456-03-025
656	46	65608-461	織部丸紋大平	1,690	1,880		656	8	13×5.5cm	220								314665608	0102480002			456-02-025
656	46	65609-461	織部丸紋毛料	2,500	2,750		656	9	15.5×6.5cm	280								314665609	0102480001			456-01-025
656	53	65610-531	三島飯碗(小)	1,850	1,950		656	10	11×5.6cm	160								315365610	0153488031			459-12-535
656	53	65611-531	三島飯碗(大)	1,900	2,000		656	11	11.3×6.2cm	190								315365611	0153488030			459-11-535
656	09	65612-091	江戸十草鑄 中平	870		廃番	656	12	11.7×5.5cm	160								310965612	0509457009			457-09-095
656	09	65613-091	江戸十草鑄 大平	970		廃番	656	13	13×5.7cm	200								310965613	0509457008			457-08-095
656	09	65614-091	江戸十草鑄 毛料	1,200		廃番	656	14	14.5×6.4cm	270								310965614	0509457007			457-07-095
656	46	65615-461	石焼ごす巻中平	1,130	1,310		656	15	12×5cm	200								314665615	0402461030			460-28-025
656	46	65616-461	石焼ごす巻大平	1,260	1,460		656	16	13×5.5cm	220								314665616	0402461029			460-27-025
656	09	65617-091	江戸十草青 中平	880		廃番	656	17	11.7×5.5cm	160								310965617	0509457006			457-06-095
656	09	65618-091	江戸十草青 大平	970		廃番	656	18	13×5.7cm	200								310965618	0509457005			457-05-095
656	09	65619-091	江戸十草青 毛料	1,200		廃番	656	19	14.5×6.4cm	270								310965619	0509457004			457-04-095
656	15	65620-151	木ズミ志野中平	750	830		656	20	11.5×5.3cm	162								251534145			51805-150	
656	15	65621-151	木ズミ志野大平	800	880		656	21	12.3×5.3cm	181								251534146			51806-150	
656	15	65622-151	木ズミ志野毛料	1,100	1,200		656	22	15×7cm	340								251537517			51807-150	
656	45	65623-451	細十草中平	1,100	1,210		656	23	11.9×5.5cm	220								314565623	0103488023			457-29-085
656	45	65624-451	細十草大平	1,160	1,280		656	24	13×5.8cm	245								314565624	0103488022			457-28-085
656	13	65625-131	志野タタキ 中平	1,100			656	25	11.7×5.5cm									311365625				
656	13	65626-131	志野タタキ 大平	1,150			656	26	12.5×5.7cm									311365626				
656	28	65627-281	野花茶碗小	1,060	1,300		656	27	11.3×5.8cm	170								252851572			51801-280	
656	28	65628-281	野花茶碗大	1,110	1,400		656	28	12.4×6.4cm	230								252851571			51802-280	
656	25	65629-251	白刷毛目茶碗(小)	1,200			656	29	11.2×5.7cm	151								292545625			51909-250	
656	25	65630-251	白刷毛目茶碗(大)	1,200			656	30	12.3×6.2cm	213								292545626			51910-250	
656	51	65631-511	益子荒刷毛茶碗(小)	1,100	1,300		656	31	11×5.7cm	183								315165631	0151488047			460-26-515
656	51	65632-511	益子荒刷毛茶碗(大)	1,200	1,400		656	32	12×6.2cm	202								315165632	0151488046			460-25-515
656	57	65633-571	白志野 中平	1,000		廃番	656	33	12×5.5cm	160								315765633	0330454030			460-30-305
656	57	65634-571	白志野 大平	1,060		廃番	656	34	13×6.5cm	220								315765634	0330454029			460-29-305
656	31	65635-311	結晶天目 中平	990	1,080		656	35	11.5×5.3cm	195								283137643			51808-310	
656	31	65636-311	結晶天目 大平	1,060	1,160		656	36	12.6×5.9cm	165								283137644			51809-310	
656	32	65637-321	織部鍋十草 中平	1,100			656	37	11.3×6cm	143								293245711			51803-320	
656	32	65638-321	織部鍋十草 大平	1,200			656	38	12.3×6.9cm	175								293245648			51804-320	
656	15	65639-151	灰釉十草 中平	870			656	39	12.2×5.7cm	210								251534159			51810-150	
656	15	65640-151	灰釉十草 大平	920			656	40	13.6×5.8cm	268								251534160			51811-150	
656	32	65641-321	さび十草 中平	880			656	41	11.3×6cm	154								273236514			51812-320	
656	32	65642-321	さび十草 大平	1,020			656	42	12.2×6.1cm	193								273236515			51813-320	
656	32	65643-321	北大地 中平	830			656	43	11.6×6cm	162								293245566			51816-320	
656	32	65644-321	北大地 大平	940			656	44	12.3×6.1cm	183								293245567			51817-320	
656	30	65645-301	白刷毛 中平	810			656	45	11×6.2cm	160								263034736			51814-300	
656	30	65646-301	白刷毛 大平	860			656	46	11.5×6.6cm	200								263034737			51815-300	
656	65	65647-651	サビボカシ 淵波 中平	720			656	47	10.8×6.4cm	164								316565647	0166488025			460-44-685
656	65	65648-651	サビボカシ 淵波 大平	780			656	48	11.5×6.8cm	187								316565648	0166488024			460-43-685
656	08	65649-081	鳳志野飯碗	4,200			656	49	11.8×4.8cm	150								270836401			51822-080	
656	12	65650-121	新織部めし碗	3,800			656	50	11.7×5.7cm									301251823			51823-120	
656	28	65651-281	黒絵格子紋三角飯碗(大)	3,300	4,100		656	51	14×6cm	210								282837534			51827-280	
656	08	65652-081	織部かぶ茶碗	3,250			656	52	11.2×5.9cm	192								280837701			51825-080	
656	47	65653-471	染付草花くらわんか茶碗	3,100	3,500		656	53	12×6.3cm	200								314765653	0547459013			459-13-475
656	08	65654-081	青釉飯碗	3,000			656	54	12.6×6.3cm									300851828			51828-080	
656	08	65655-081	織部間取花和茶碗	3,000			656	55	12.5×6cm	197								290845603			51831-080	
656	08	65656-081	美濃飯碗	3,000			656	56	12.6×6.3cm									300851829			51829-080	
656	08	65657-081	錆草文和茶碗	3,000			656	57	12.5×6cm	183								290845604			51824-080	
656	08	65658-081	黒釉天目流し飯碗	3,000			656	58	13×6.4cm									300851830			51830-080	
656	47	65659-471	赤絵木の葉浜四角茶碗	2,700	3,000		656	59	11.8×6cm	170								314765659	0147484009			459-16-475
656	08	65660-081	すだれ丸茶碗	2,650			656	60	11.1×5.8cm									300851834			51834-080	
656	43	65661-431	灰刷毛目飯碗	2,700			656	61	12×7.5cm	200								274336407			51836-430	
656	22	65662-221	淵唐草反飯碗	2,550	3,000		656	62	12.5×6.7cm	180								262234609			51837-220	
656	12	65663-121	粉引織部散し高台お茶漬碗	2,500			656	63	13×9.1cm	253								301251826			51826-120	
656	33	65664-331	絵黒織部茶碗	2,400	2,850		656	64	11.5×6cm	200								293345610			51840-330	
656	30	65665-301	織部和み黒土 中平	2,400		廃番	656	65	12.5×6cm	160								283037621			51843-300	

656	03	65666-031	手彫焼×京型4.0井	2,400	2,600	656	66	11.5×7.3cm	252								280337619			51842-030	
656	12	65667-121	粉引織部散し飯碗	2,300		656	67	11.3×5.8cm	175								301251841			51841-120	
656	47	65668-471	つなぎ十草浜四角茶碗	2,250	3,000	656	68	11.8×6cm	200								314765668	0147484010			459-19-475
657	14	65701-141	黒織部平茶碗	2,200	2,300	657	1	14.5×5.5cm	198								311465701	0410460013			459-24-105
657	14	65702-141	黄瀬戸織部平茶碗	2,200	2,300	657	2	14.5×5.5cm	209								311465702	0410460012			459-23-105
657	45	65703-451	花見茶碗	2,200	2,500	657	3	12.8×6.2cm									304551839			51839-450	
657	08	65704-081	焼締彫十草新飯碗	2,000		657	4	11×6.3cm	188								270836424			51838-080	
657	36	65705-361	粉引そぎ飯碗	2,000		657	5	11.6×6cm	210								313665705	0424461004			459-36-245
657	14	65706-141	染唐草茶碗	2,000	2,100	657	6	12×6cm	193								311465706	0410460019			459-27-105
657	36	65707-361	粉引面取飯器	2,000	2,100	657	7	11×7.3cm	240								313665707	0124489017			459-30-245
657	14	65708-141	点十草茶碗	2,000	2,100	657	8	12×6cm	190								311465708	0410460016			459-29-105
657	14	65709-141	黒土化粧茶碗	2,000	2,100	657	9	12×6cm	204								311465709	0410460018			459-28-105
657	14	65710-141	織部茶碗	2,000	2,100	657	10	12×6cm	188								311465710	0410460015			459-25-105
657	14	65711-141	染十草茶碗	2,000	2,100	657	11	12×6cm	210								311465711	0410460017			459-26-105
657	33	65712-331	錆唐草波型飯碗	2,000	2,200	657	12	12×7cm	200								293345614			51844-330	
657	14	65713-141	染十草姫茶碗	1,900	2,000	657	13	11.5×6cm	141								311465713	0410460030			460-01-105
657	14	65714-141	黄瀬戸織部姫茶碗	1,900	2,000	657	14	11.5×6cm	128								311465714	0410460028			459-42-105
657	14	65715-141	粉引渦姫茶碗	1,900	2,000	657	15	11.5×6cm	160								311465715	0410460031			460-03-105
657	14	65716-141	黒織部姫茶碗	1,900	2,000	657	16	11.5×6cm	127								311465716	0410460029			460-02-105
657	14	65717-141	粉引三鳥茶碗	1,850	1,950	657	17	11.5×6cm	164								311465717	0110487024			459-38-105
657	31	65718-311	織部舞桜茶碗	1,800	1,980	657	18	12.8×6.2cm・300cc	60								313165718				
657	03	65719-031	一珍紅丸紋中平	1,800	2,300	657	19	12.3×6.7cm	233								260334642			51849-030	
657	03	65720-031	黄地天目十草中平	1,800	2,000	657	20	11.2×6.5cm	204								250334019			51850-030	
657	49	65721-491	粉引削ぎ茶碗	1,800	1,980	657	21	12.5×6.7cm	260								314965721	0249470013			459-35-495
657	03	65722-031	いらほ梅花木深口丸碗	1,800	2,000	657	22	11.3×7.2cm	246								270336437			51851-030	
657	33	65723-331	灰吹茶碗	1,750	1,950	657	23	12×5.5cm	189								253334016			51846-330	
657	33	65724-331	ゴス点茶碗	1,750	1,950	657	24	12×5.5cm	188								253334168			51845-330	
657	03	65725-031	かいらぎ緑釉中平	1,700	2,000	657	25	11×6.2cm	148								300351902			51902-030	
657	36	65726-361	ひよっこ小碗	1,700		657	26	10.5×6.5cm	180								313665726				
657	36	65727-361	おかめ小碗	1,700		657	27	10.5×6.5cm	180								313665727				
657	57	65728-571	削ぎ茶碗 ヒスイ	1,650		657	28	12.5×6.5cm・320cc	220								315765728	0530454007			454-07-305
657	57	65729-571	削ぎ茶碗 紺	1,650		657	29	12.5×6.5cm・320cc	220								315765729	0530454008			454-08-305
657	43	65730-431	黒窯変掛け分け飯碗	2,000		657	30	10.8×7cm	183								294345641		(信楽焼)	51904-430	
657	05	65731-051	白うるし飯碗	1,600	1,700	657	31	11.2×6.8cm	210								290545634			51903-050	
657	25	65732-251	かいらぎ白飯碗	1,650		657	32	11.5×6.5cm	200								302551848			51848-250	
657	08	65733-081	アイシングご飯茶碗 ネイビー	1,650	1,900	657	33	11.5×7.4cm	250								310865733				
657	08	65734-081	アイシングご飯茶碗 白	1,650	1,900	657	34	11.5×7.4cm	250								310865734				
657	08	65735-081	ボーダー切立飯碗小	1,500		657	35	12.4×6.3cm	221								310865735				
657	08	65736-081	富士山切立飯碗小	1,500		657	36	12.4×6.3cm	221								310865736				
657	12	65737-121	さび織部飯碗	1,600		657	37	12×7.2cm									311265737				
657	08	65738-081	うるし黒ボール型飯碗	1,550	1,580	657	38	10.8×6.7cm									300851847			51847-080	
657	08	65739-081	うるし白ボール型飯碗	1,550	1,580	657	39	10.8×6.7cm	220								290845631			51852-080	
657	64	65740-641	いぶし金茶碗	1,500		鹿香	657	40	11.8×6cm	268							316465740	0164487010			459-41-645
657	28	65741-281	トルコ釉飯碗	1,450	1,800	657	41	12×6.8cm									312865741				
657	28	65742-281	白釉飯碗	1,450	1,800	657	42	12×6.8cm									312865742				