

頁	商社	Vol.31品番	品名	Vol.31上代(紙版)	上代変更	廃番	頁	順	サイズ	重量g	強化	直火OK	軽量	耐熱	IH	原産国	有田焼	永久番号	旧永久番号(旧雅陶会)	備考	品番(旧陶里)	品番(旧雅陶会)
796	01	79601-011	明世荒刷毛 多用碗(小)	620	760		796	1	13×7cm	352								270157262			61302-010	
796	01	79602-011	明世荒刷毛 6.5麺井	1,280	1,540		796	2	19.7×9.5cm	795								270157263			61303-010	
796	01	79603-011	明世荒刷毛 5.5多用井	930	1,160		796	3	17.5×9cm	598								270157264			61304-010	
796	01	79604-011	明世荒刷毛 5.5釜上井	1,140	1,580		796	4	17×9cm	719								270157265			61305-010	
796	01	79605-011	明世荒刷毛 8.0握り深鉢	2,200	2,840		796	5	24×8cm	1083								270157266			61306-010	
796	01	79606-011	明世荒刷毛 9.5ミツワ盛皿	2,280	2,920		796	6	29×6cm	1079								254719916			61307-010	
796	01	79607-011	明世荒刷毛 7.5ミツワ麵皿	850	1,080		796	7	23×5cm	565								254719915			61308-010	
796	01	79608-011	明世荒刷毛 8.0盛鉢	1,660	1,820		796	8	24.5×7cm	887								270157261			61301-010	
796	01	79609-011	明世荒刷毛 呑水	430	490		796	9	13×12×4.5cm	170								270157269			61309-010	
796	01	79610-011	明世荒刷毛 ミツワカレー皿	710	790		796	10	20×4cm									300161318			61318-010	
796	01	79611-011	明世荒刷毛 9.0盛鉢	2,170	2,480		796	11	28×7.4cm									300161319			61319-010	
796	01	79612-011	明世荒刷毛 3.5皿	370	420		796	12	12.2×2cm	128								270157270			61310-010	
796	01	79613-011	明世荒刷毛 4.0皿	430	490		796	13	13×2cm									300161316			61316-010	
796	01	79614-011	明世荒刷毛 5.0皿	490	610		796	14	16.7×2.3cm	238								270157271			61311-010	
796	01	79615-011	明世荒刷毛 6.0皿	720	860		796	15	19×2.8cm									300161317			61317-010	
796	01	79616-011	明世荒刷毛 7.0皿	960	1,080		796	16	22.8×3cm	546								270157272			61312-010	
796	01	79617-011	明世荒刷毛 8.0皿	1,430	1,550		796	17	25.5×3.5cm	716								270157273			61313-010	
796	01	79618-011	明世荒刷毛 9.0皿	2,170	2,270		796	18	28.7×3.6cm	986								270157274			61314-010	
796	01	79619-011	明世荒刷毛 10.0皿	4,300	4,740		796	19	31.5×4.2cm	1028								270157275			61315-010	
796	01	79651-011	雪志野 バスタ皿	1,400	1,720		796	51	21.8×4.5cm	705								270156552			61351-010	
796	01	79652-011	雪志野 5.5多用井	930	1,160		796	52	17.3×9cm	590								270156553			61352-010	
796	01	79653-011	雪志野 5.5釜上井	1,190	1,580		796	53	17×9cm	730								270156554			61353-010	
796	01	79654-011	雪志野 5.0和井	710	880		796	54	15.9×7.9cm	455								270156556			61354-010	
796	01	79655-011	雪志野 8.0盛鉢	1,520	1,820		796	55	24.5×8.2cm	880								270156557			61355-010	
796	01	79656-011	雪志野 手捻り姫井	780	980		796	56	13.5×8cm	360								270156558			61356-010	
796	01	79657-011	雪志野 5.5くくり鉢	880	1,100		796	57	17.3×6cm	480								270156559			61357-010	
796	01	79658-011	雪志野 8.0くくり鉢	2,200	2,640		796	58	23.5×8cm	1150								270156560			61358-010	
796	01	79659-011	雪志野 9.5ミツワ皿	2,230	2,930		796	59	28.6×6cm	1040								254719914			61359-010	
796	01	79660-011	雪志野 多用碗(小)	620	770		796	60	13×7.2cm	355								270156562			61360-010	
796	01	79661-011	雪志野 9.0深皿	1,650	2,310		796	61	28.3×3.7cm	950								270156563			61361-010	
796	01	79662-011	雪志野 4.0くくり鉢	530	610		796	62	12.9×4.8cm	270								270156564			61362-010	
796	01	79663-011	雪志野 4.5正角皿	500	570		796	63	13.7×13.7×3.2cm	240								270156565			61363-010	
796	01	79664-011	雪志野 5.5正角皿	870	1,050		796	64	17.3×17.3×3.3cm	410								270156566			61364-010	
796	01	79665-011	雪志野 4.0皿	430	490		796	65	13.3×2.3cm	165								270156567			61365-010	
796	01	79666-011	雪志野 5.0皿	550	600		796	66	16.7×2.3cm	250								270156568			61366-010	
796	01	79667-011	雪志野 7.0皿	850	1,080		796	67	22.8×3.2cm	575								270156569			61367-010	
796	01	79668-011	雪志野 8.0皿	1,280	1,570		796	68	25.6×3.5cm	770								270156570			61368-010	
796	01	79669-011	雪志野 6.0皿	730	860		796	69	19×3cm									300161369			61369-010	
796	01	79670-011	雪志野 9.0皿	2,020	2,270		796	70	28.5×3.5cm									300161370			61370-010	
796	01	79671-011	雪志野 10.0皿	4,270	4,730		796	71	31×4.5cm									300161371			61371-010	
796	01	79672-011	雪志野 ミツワカレー皿	710	800		796	72	20×4cm									300161372			61372-010	
796	01	79673-011	雪志野 9.0盛鉢	2,150	2,480		796	73	28×7.4cm									300161373			61373-010	
796	01	79674-011	雪志野 呑水	430	490		796	74	13×12×5cm									300161374			61374-010	
797	01	79701-011	立春刷毛 5.5多用井	920	1,100		797	1	17×8.9cm	563								270156501			60951-010	
797	01	79702-011	立春刷毛 4.0深鉢	530	570		797	2	13×5.5cm	248								270156502			60952-010	
797	01	79703-011	立春刷毛 5.5釜上井	1,200	1,500		797	3	17.3×9cm	711								270156503			60953-010	
797	01	79704-011	立春刷毛 6.5高台腰張井	1,630	1,780		797	4	20×8.3cm	709								270156505			60954-010	
797	01	79705-011	立春刷毛 手捻り姫井	770	940		797	5	13.5×8.2cm	322								270156506			60955-010	
797	01	79706-011	立春刷毛 5.8そば井	670	830		797	6	18×7.5cm	412								270156507			60956-010	
797	01	79707-011	立春刷毛 6.5そば井	870	1,000		797	7	19.8×8.1cm	532								270156508			60957-010	
797	01	79708-011	立春刷毛 大茶	660	730		797	8	15.5×7.2cm	286								270156509			60958-010	
797	01	79709-011	立春刷毛 9.5優器盛鉢	3,250		廃番	797	9	28.4×7cm	863								270156510			60959-010	
797	01	79710-011	立春刷毛 4.0手捻りボール	500	460		797	10	13.4×4.5cm	235								270156513			60960-010	
797	01	79711-011	立春刷毛 8.0手捻り盛鉢	1,400	1,880		797	11	24×5.7cm	682								270156511			60961-010	
797	01	79712-011	立春刷毛 3.0皿	370	400		797	12	10.1×1.8cm	79								270156517			60962-010	
797	01	79713-011	立春刷毛 3.5皿	370	400		797	13	12.6×2cm	116								270156518			60963-010	
797	01	79714-011	立春刷毛 4.0皿	420	460		797	14	13.5×2.1cm	144								270156519			60964-010	
797	01	79715-011	立春刷毛 5.0皿	550	570		797	15	17×2.5cm	221								270156520			60965-010	
797	01	79716-011	立春刷毛 6.0皿	740	820		797	16	19.5×2.8cm	350								270156521			60966-010	
797	01	79717-011	立春刷毛 7.0皿	1,360	1,020		797	17	23×3.1cm	527								270156522			60967-010	
797	01	79718-011	立春刷毛 8.0皿	1,300	1,500		797	18	26×3.6cm	722								270156523			60968-010	
797	01	79719-011	立春刷毛 9.0皿	1,980	2,160		797	19	28.8×4cm	932								270156524			60969-010	
797	01	79720-011	立春刷毛 10.0皿	4,300	4,510		797	20	31.5×4.1cm	1388								270156525			60970-010	
797	18	79751-181	ゆらり 粉引き7.0井	1,250	1,890		797	51	21.5×8.9cm	736								281877251			61251-180	

797	18	79752-181	ゆらり 粉引き6.5井	980	1,490	797	52	20×8cm	588							281877252		61252-180	
797	18	79753-181	ゆらり 粉引き6.0深井	1,300	2,050	797	53	18×9.3cm	582							281877253		61253-180	
797	18	79754-181	ゆらり 粉引き5.5深井	960	1,490	797	54	16.1×8.7cm	486							281877254		61254-180	
797	18	79755-181	ゆらり 粉引き5.0深井	900	1,350	797	55	15×8.3cm	403							281877255		61255-180	
797	18	79756-181	ゆらり 粉引き8.0種井	1,820	2,700	797	56	24×6.8cm	708							281877256		61256-180	
797	18	79757-181	ゆらり 粉引き8.0深皿	1,020	1,820	797	57	24.4×5cm	726							281877257		61257-180	
797	18	79758-181	ゆらり 粉引き7.0深皿	650	1,080	797	58	21×4cm	433							281877258		61258-180	
797	18	79759-181	ゆらり 粉引き4.5深皿	500	820	797	59	14.7×3.8cm	200							281877259		61259-180	
797	18	79760-181	ゆらり 粉引き3.3深皿	390	680	797	60	10×2.5cm	101							281877260		61260-180	
797	18	79761-181	ゆらり 粉引き5.5煮物皿	570	950	797	61	16.7×5.2cm	324							281877261		61261-180	
797	18	79762-181	ゆらり 粉引き4.2鉢	570	950	797	62	13×4.5cm	241							281877262		61262-180	
797	18	79763-181	ゆらり 粉引き3.8鉢	570	950	797	63	11×5.9cm	231							281877263		61263-180	
797	18	79764-181	ゆらり 粉引き4.5ライス井	740	1,220	797	64	13.6×7.8cm	314							281877264		61264-180	
797	18	79765-181	ゆらり 粉引き3.8ライス小鉢	560	950	797	65	12.7×6.3cm	189							281877265		61265-180	
797	18	79766-181	ゆらり 粉引きソバ千代口小鉢	510	820	797	66	9.4×6.2cm・190cc	136							281877267		61266-180	
797	18	79767-181	ゆらり 粉引き9.0皿	1,590	2,450	797	67	27.7×3.3cm	739							281877268		61267-180	
797	18	79768-181	ゆらり 粉引き8.0皿	1,020	1,820	797	68	24.8×3.3cm	632							281877269		61268-180	
797	18	79769-181	ゆらり 粉引き7.0皿	650	1,080	797	69	21.3×2.5cm	418							281877270		61269-180	
797	18	79770-181	ゆらり 粉引き5.5皿	500	850	797	70	16.3×2.5cm	250							281877271		61270-180	
797	18	79771-181	ゆらり 粉引き4.5皿	460	820	797	71	14.4×2.3cm	172							281877272		61271-180	